

Megawin

8051 OCD ICE

User Manual

Contents

1	Introduction	3
	Features	3
	Description	3
2	Hardware Setup	4
3	Software Setup	6
	3.1 Install the USB Device Driver for the ICE Adapter	6
	3.2 Install the Megawin 8051 Database in the Keil 8051 IDE Software	6
4	Keil IDE Setup	7
	4.1 Options- Device	8
	4.2 Options- Target	8
	4.3 Options- Output	9
	4.4 Options- C51	9
	4.5 Options- Debug	10
	4.6 Options- Utilities	11
5	Start Debugging	12
	5.1 Activate the <i>dScope</i> -Debugger Function	12
	5.2 Introduction to the Debugger Environment	13
	5.2.1 Reset/Run/Halt/Step/Run-to-Cursor	14
	5.2.2 Source-Level Debugging	14
	5.2.3 Breakpoint Setting	15
	5.2.4 View/Edit the Contents of Peripherals' SFRs	16
	5.2.5 View- Disassembly Window	17
	5.2.6 View- Watch Window	18
	5.2.7 View- Memory Window	19
6	Tools, Megawin ICP	20
	6.1 About ICP	20
	6.2 Use ICP	20
	6.2.1 Update Programmer	21
	6.2.2 Update Target	26
7	Special Notes	27
	7.1 Register Definition Files	27
	7.2 On-chip XRAM and External Data Memory	27
	7.3 Code Optimization and Source-Level Debugging	28
	7.4 "for-Loop" and Source-Level Debugging	29
	7.5 Hardware Option Requirements During Debugging	29
	7.6 Error Message	30
	7.7 Properly Connect the ICE Adapter to a Host	31
	Revision History	32

1 Introduction

Features

- Megawin proprietary OCD (On-Chip-Debug) technology
- On-chip & in-system real-time debugging
- Two-pin dedicated serial interface for OCD, no target resource occupied
- Directly linked to the debugger function of the *Keil 8051 IDE Software*
- USB connection between target and host (PC)
- Helpful debug actions: *Reset, Run, Stop, Step* and *Run to Cursor*
- Programmable breakpoints, up to 4 breakpoints can be inserted simultaneously
- Several debug-helpful windows: Register/Disassembly/Watch/Memory Windows
- Source-level (*Assembly* or *C-language*) debugging capability

Description

The all new “Megawin 8051 OCD ICE” is a powerful development tool for 8051 embedded system. By adopting the Megawin proprietary OCD (On-Chip-Debug) technology, this ICE provides on-chip and in-system real-time debugging. The user has no need to prepare any development board during developing, or the socket adapter used in the traditional ICE probe. All the thing the user needs to do is to reserve a 6-pin connector for the dedicated OCD interface: *VCC, OCD_SDA, OCD_SCL, RST, CLK* and *GND*.

In addition, the most useful feature is that it can directly connect the user’s target system to the *Keil 8051 IDE software* for debugging, which directly utilizes the Keil IDE’s *dScope-Debugger* function. Of course, all the advantages are based on your using *Keil 8051 IDE software*.



Note:

“Keil” is the trade mark of “Keil Elektronik GmbH and Keil Software, Inc.”, and “Keil 8051 IDE software” is the most popular C51 compiler for 8051 embedded system development.

2 Hardware Setup

For debugging, the user should connect the target system to a PC via the ICE adapter, as shown below. The ICE adapter is a bus-powered USB device, and therefore there is no need of a power adapter for it.

Hardware Connection Diagram



Note: Refer to [Section 6.5](#) for more information.

OCD ICE Interface Pin Number

Part No.	Package	OCD_SCL	OCD_SDA	RST	CLK
MPC82G516	40-pin DIP	29	30	N/A	N/A
	44-pin PLCC	32	33	N/A	N/A
	44-pin QFP	26	27	N/A	N/A
MG82FL(E)532/564	44-pin QFP	26	29	4	5
	48-pin LQFP	28	32	5	6
MG84FG516	48-pin LQFP	26	27	25	N/A
	64-pin LQFP	34	35	33	N/A
MG82FG5A32/5A64	48-pin LQFP	26	27	25	N/A
	64-pin LQFP	34	35	33	N/A
MG82FG5Bxx	28-pin SOP	27	28	26	N/A
	32-pin LQFP	18	19	17	N/A
MG82FG5Cxx	48-pin LQFP	26	27	25	N/A

	64-pin LQFP	34	35	33	N/A
MG82FG5Dxx	16-pin SOP	15	16	14	N/A
	20-pin SSOP	19	20	18	N/A

****N/A : No need to connect**

3 Software Setup

This section tell the user how to do software setup before using the OCD ICE.

3.1 Install the USB Device Driver for the ICE Adapter

The user just needs to plug the ICE adapter into any USB port in a PC. There is no need to install any device driver for the ICE adapter.

3.2 Install the Megawin 8051 Database in the Keil 8051 IDE Software


Activate the "Setup.exe" in the folder [Database Installer] to open the *Database Installer Application Program* to install the Megawin Database into the Keil 8051 IDE software. Of course, you should have installed the Keil 8051 IDE software, either μ Vision2 or μ Vision3, in your PC previously.

After opening the *Database Installer*, please follow the steps shown in the following GUI figure.

Step1) Click the **Browse** button to specify where the Keil software has been installed.
(Normally, when you install the Keil 8051 IDE software, the default install-path is "C:\KEIL".)


Step2) Click the **Install** button to start installing the Megawin Database into the Keil software.

GUI of the Database Installer




4 Keil IDE Setup

Before using the *dScope-Debugger* function of the Keil IDE, the user should do some proper settings in the Keil IDE. First, open the *µVision* project you would like to debug. Then, move cursor to “Target-..” and click the mouse’s right button to invoke the “**Options for Target**”, as shown below.




4.1 Options- Device

Select the “Megawin Device Database” and the target part number.




4.2 Options- Target

Enable the “Use on-chip ROM” and the “Use on-chip XRAM”.




4.3 Options- Output

Enable the “Debug Information”. It is necessary for creating an absolute OMF file for source-level debugging.




4.4 Options- C51

Disable the code optimization by selecting “Level 0: Constant folding”. Refer to [Section 6.3](#) for more information about this setting. *Note: This setting is optional.*




4.5 Options- Debug

Select the “Megawin On-Chip-Debug Driver”.




And, enable the “Load Application at Startup” and all the Cache Options.



4.6 Options- Utilities

Always disable the “Update Target before Debugging”. It is because we have enabled the “Load Application at Startup” shown in [Section 4.5](#). And, leave the “Use Target Driver for Flash Programming” *don't-care*.

Note: *μVision2* doesn't have this selection item.




5 Start Debugging

After the tasks described in *Sections 2, 3 and 4* have been done, you can start debugging your μ Vision project.

5.1 Activate the dScope-Debugger Function

After building the project (suppose no error), you can enter the Keil IDE's debugger mode by clicking the *dScope* button, as shown below. Now, the project code will be automatically downloaded into the target's Flash. It will take some time.



5.2 Introduction to the Debugger Environment

There are four basic windows regarding the debugging operation in the debugger environment. They are Register Window, Disassembly Window, Watch Window and Memory Window, as described below.

Register Window

This window shows the contents of the current register bank (R0~R7), the system registers (A, B, SP, DTPR and the Program Counter) and the Program Status Word (PSW). The register with blue background means its content is just changed due to the instruction just executed.

Disassembly Window


This window is the default window opened just when the debugger mode is entered. It shows the source-level code followed by its corresponding assembly code.

Watch Window

This window automatically shows the local variables when **Locals** is clicked. The local variables are the variables declared within a function including the main() function. To view the global variables, click **Watch #1** or **Watch #2** and type <F2> key to edit and enter the variable name. The variable with blue background means its content is just changed due to the instruction just executed.

Memory Window

This window shows the contents of the memory located at the **data/idata/xdata/code** memory space. The available commands are: d:0x00~d:0xFF, i:0x00~i:0xFF, x:0x0000~x:0xFFFF and c:0x0000~c:0xFFFF. The user can view any of the four memory by entering the corresponding command.




The screenshot displays the Megawin On-Chip-Debug Driver interface with the following windows:

- Register Window:** Shows the contents of registers r0-r7, Sys (a, b, sp, dptr, PC, psw). The 'sp' register is highlighted with a blue background.
- Disassembly Window:** Shows source code and assembly instructions. The assembly instruction 'LED_blinking(C:0357)' is highlighted.
- Watch Window:** Shows local variables L_var1 through X_var2. The variable 'L_var1' is highlighted with a blue background.
- Memory Window:** Shows memory contents starting from address x:0x0000. The memory address 'x:0x0000' is highlighted.

The status bar at the bottom indicates 'Ready' and 'Megawin On-Chip-Debug Driver t1: 0.00000000 sec'.


5.2.1 Reset/Run/Halt/Step/Run-to-Cursor

Reset, Run, Halt (Stop), Step and Run-to-Cursor are the basic debug actions. The user can easily invoke any of these actions by clicking the short-cut buttons in the debugger GUI, as shown below.



5.2.2 Source-Level Debugging

To do the source-level debugging, open the source file by clicking **Files** to open the Project Workspace and select the source files you want. Click **Regs** again to return to Register Window, as shown below.




5.2.3 Breakpoint Setting

There are total four breakpoints available for debugging. Up to four breakpoints can be inserted simultaneously.


Insert/Remove a Breakpoint

Move the cursor to the front of the line and click the right key, then click **"Insert/Remove Breakpoint"** for toggling between Insert and Remove, as shown below.




Enable/Disable a Breakpoint

Move the cursor to the front of the line and click the right key, then click **"Enable/Disable Breakpoint"** for toggling between Enable and Disable. Of course, this line should have been inserted a breakpoint previously.



5.2.4 View/Edit the Contents of Peripherals' SFRs

There are many peripheral SFRs that don't belong to the registers shown in the Register Window. To view or edit these registers, select the **Peripherals** item on the main menu. A pulled-down sub-menu will be displayed, and the user can select a peripheral to view or edit its corresponding SFRs, as shown below.



The screenshot shows the Megawin IDE interface with the **Peripherals** menu open. The menu options are: Reset CPU, Interrupt, I/O Ports, Timer, Serial Port, A/D Converter, Keypad Interrupt, SPI, PCA, XRAM, Others, ISP, and Target Settings. The **PCA** option is highlighted. Red arrows point from the text "Select any peripheral you want to check or edit" to the menu and from "These peripherals have been opened for checking" to the peripheral windows.

I/O Ports window:

P0: 0x FF	P0M0: 0x 00	P0M1: 0x 00
P1: 0x FF	P1M0: 0x 00	P1M1: 0x 00
P2: 0x FF	P2M0: 0x 00	P2M1: 0x 00
P3: 0x FF	P3M0: 0x 00	P3M1: 0x 00
P4: 0x FF	P4M0: 0x 00	P4M1: 0x 00

Timer/Counter window:

TMOD: 0x 00	TCON: 0x 00
T2MOD: 0x 00	T2CON: 0x 00
RCAP2H: 0x 00	RCAP2L: 0x 00
TH0: 0x 00	TL0: 0x 00
TH1: 0x 00	TL1: 0x 00
TH2: 0x 00	TL2: 0x 00

Register Window:

Register	Value
r0	0x00
r1	0x00
r2	0x00
r3	0x00
r4	0x00
r5	0x00
r6	0x00
r7	0x00
dptr	0x0000
PC	0x02ef
psw	0x00

Locals Window:


Name	Value
L_var1	0x00
L_var2	0x00
L_var3	0x00
L_var4	0x0000
L_var5	0x0000
X_var1	0x00
X_var2	0x00

Memory Window:


Address	Value
0x000000	00 00 DF E0 6B 71 77 FD
0x000008	BB 1A 3C D7 AE 73 5C 38
0x000010	DC E7 39 B5 F6 9F C9 14
0x000018	D2 ED AF EF FA 1D 31 C7
0x000020	F6 4F 30 DE 8E EA AA 5B
0x000028	CD 19 39 CF F7 1B F9 49
0x000030	D7 AB D4 65 7F DB 77 B7
0x000038	5F 6F 18 B9 A5 7E B5 5F

5.2.5 View- Disassembly Window

Disassembly Window displays source-level code followed by its corresponding assembly. To open this window, select the **View** item on the main menu. A pulled-down sub-menu will be displayed, and then select **Disassembly Window**, as shown below.




Maximize the Disassembly Window for detailed description:




5.2.6 View- Watch Window

The Watch Window helps the user to check either local variables or global variables, as shown below.



To check the global variables, click **Watch #1** or **#2**, then type <F2> key to enter the variable name.




5.2.7 View- Memory Window

To open this window, select the **View** item on the main menu. A pulled-down sub-menu will be displayed, and then select **Memory Window**, as shown below. The available commands are:

- (1) d:0x00~d:0xFF, for 'data' type
- (2) i:0x00~i:0xFF, for 'idata' type
- (3) x:0x0000~x:0xFFFF, for 'xdata' type
- (4) c:0x0000~c:0xFFFF., for 'code' type

The user can view any of the four memory by entering the corresponding command. Refer to [Section 6.2](#) for how to display 'xdata' type variables.



6 Tools, Megawin ICP

6.1 About ICP


ICP is the acronym of In-Circuit Programming. Users can update the application code under the software control without removing the mounted MCU chip from the actual end product. In addition, because the programming data to be programmed to the target can be saved in the ICE adapter's non-volatile storage, this **stand-alone** programmer is able to work without host(PC) intervention. This feature is especially useful in the field without a PC.

6.2 Use ICP

Here are the two ways of opening ICP application:

1. Execute "ICPProgrammer.exe" under "\C51\INC\Megawin\" of Keil's Install folder.
2. Click "Tools\Megawin ICP" from Keil's Menu bar.


Attention: To program ICP application correctly by means 2, users have to open Project and Build first.



6.2.1 Update Programmer


Step 1: Choose a “MCU Part No.”

If users open ICP application by clicking Menu, Step 1 can be omitted. ICP application will choose MCU Part No. by Project automatically.




Step 2: Click "Load File" and choose loading AP(Code) or IAP(Data). "Load File" can be clicked repeatedly to load different files. While loading IAP(Data), users have to key in Address. HEX and BIN data formats are supported for file loading.

If users open ICP application by clicking Menu, Step 2 can be omitted. ICP application will load Target file automatically.




Step 3: Click “Insert ISP-Code” may choose to insert Megawin-provided ISP code or User-defined ISP code.

If ISP function is not needed, Step 3 can be omitted.



Step 4: H/W Option Setting



The screenshot shows the Megawin 8051 ICP Programmer software interface. The title bar reads "Megawin 8051 ICP Programmer". The main window features the Megawin logo and several configuration sections. A red box highlights the "H/W Option Setting" section, which includes the following controls:


- ISP-memory:** A dropdown menu set to "None".
- IAP-memory:** A dropdown menu set to "1.5 K" and a text field for "IAPLB:" containing "FA00h".
- HWENW:** A checkbox that is unchecked.
- HWWIDL:** A checkbox that is unchecked.
- HWPSx:** A dropdown menu set to "F/256".
- HW Options (checkboxes):**
 - HWBS (unchecked)
 - LOCK (unchecked)
 - BO1S00 (unchecked)
 - BO1S10 (unchecked)
 - HWBS2 (unchecked)
 - BO0RE0 (unchecked)
 - BO1RE0 (unchecked)
 - WRENO (unchecked)
 - HWENW (unchecked)
 - NSWDT (unchecked)
 - WDSFWP (unchecked)

Other visible sections include:

- Programmer Type:** Radio buttons for ISP and ICP (ICP is selected).
- MCU Part No:** A dropdown menu showing "MG84FG516".
- Update HW Option:** Radio buttons for No and Yes (Yes is selected).
- Programming Area:** Radio buttons for AP, IAP, ISP, AP+IAP, and Whole-chip (Whole-chip is selected).
- Buttons:** Load File, Update Target, Insert ISP-Code, Update Programmer, Exit, and Dump Target Info.
- Binary Code Buffer:** A large empty text area at the bottom of the window.

Step 5: Click "Update Programmer" to download programming data to the ICE adapter.

"Update Programmer" function can be chosen only when connecting an ICE adapter (Only support TH065C or later versions).



The screenshot shows the Megawin 8051 ICP Programmer software interface. The window title is "Megawin 8051 ICP Programmer". The interface includes several sections:

- Programmer Type:** Radio buttons for ISP and ICP (ICP is selected).
- MCU Part No:** A dropdown menu showing "MPC82G516".
- Update HW Option:** Radio buttons for No and Yes (Yes is selected).
- Buttons:** "Load File", "Update Target", "Insert ISP-Code", "Update Programmer" (highlighted with a red rectangle), "Exit", and "Dump Target Info".
- Programming Area:** Radio buttons for AP, IAP, ISP, AP+IAP, and Whole-chip (Whole-chip is selected).
- HW Option Setting:**
 - ISP-memory:** A dropdown menu showing "None".
 - IAP-memory:** A dropdown menu showing "3.0 K" and a text field for "IAPLB:" showing "F400h".
 - HWENW:** A checkbox for "HWWIDL" (unchecked) and a dropdown menu for "HWPSx" showing "F/256".
 - Checkboxes:** LOCK, SB, HWBS, ENLVRC, ENLVRO, HWBS2, OSCDN, HWENW, WDSFWP, ENROSC, and ENLVRO.
- Binary Code Buffer:** A table showing hexadecimal addresses and data. The data is displayed in a grid with columns for addresses and data bytes. The data is shown in hexadecimal and ASCII (e.g., ".LQ!u.Zu.[u.\u.", ".u.4u.Vu.xu.8u.?", "?to?.t u.格", ".坳.移...???.鍍u", "...?脰.P.??` ?", "t'. ...e鎔...?", "?P.??e ?tE.", "...e鑛廠u..u..繡", "...P.???t.-餘", "t.<鍍鍍...?p...E", "鍍?u..u..繡.?P", "...鍍 ??t.-餘t", "...鍍鍍...?p...E?", "QXQ^QdQjQIQaQgQm").
- Size and Checksum:** "Size = 624 Bytes" and "Checksum = 0xE5B2".

6.2.2 Update Target

How to update the target? Users may

1. click "Update Target" to program on-line update, referring to steps 1 through 4 of 6.2.1 Update Programmer, or
2. click "Downloading" of ICE adapter to program off-line update, referring to 6.2.1 Update Programmer.



7 Special Notes


7.1 Register Definition Files

Register definition files *REG_MPC82G516.INC* and *REG_MPC82G516.H* define all Special Function Registers (SFRs) and bit-addressable control/status bits. They are installed into the default search path used by the Keil 8051 IDE software when you do the Software Setup (described in Section 2). Therefore, when using the Keil 8051 tools, you can include them by `$INCLUDE (REG_MPC82G516.INC)` and `#include <REG_MPC82G516.H>`. It is not necessary to copy a register definition file to each project's file directory.

7.2 On-chip XRAM and External Data Memory

Megawin 8051 devices provide on-chip XRAM (eXpanded RAM), which is accessed with the same instructions as the traditional external data memory. The size of on-chip XRAM in MPC82G516 is 1024 bytes with addresses 0x0000 to 0x03FF. That is, the address space of on-chip XRAM overlaps that of the external data memory. So, there must be a control bit used to distinguish these two physical memories during access. The ERAM bit (bit-1 in register AUXR) plays this role. *Because the C51 Compiler won't take care which physical memory the user wants to access, the user must manually clear this bit before accessing on-chip XRAM and set this bit before accessing external data memory.* By default, this control bit is '0' after powered on or chip reset for on-chip XRAM accessing.

The C51 Compiler offers two different memory types that access external data: *xdata* and *pdata*. (The *xdata* memory specifier refers to any location in the 64K-byte address space of external data memory. The *pdata* memory type specifier refers to only one page or 256 bytes of external data memory.) When the user want to view the variables declared by *xdata* or *pdata* directly in the Memory Window rather than in the Watch Window, he should select “**Display xdata from on-chip XRAM**” or “**Display xdata from external RAM**” under menu **Peripherals- XRAM**, as shown in the following figure.



The following example code shows how to use both on-chip XRAM and external RAM in an application. To view G_array1[], select “Display xdata from on-chip XRAM”; and to view G_array2[], select “Display xdata from external RAM”.

Example of using both on-chip XRAM and external RAM

```
unsigned char xdata G_array1[512] _at_ 0x0000; // in 'xdata' space, will use on-chip XRAM
unsigned char xdata G_array2[512] _at_ 0x0000; // in 'xdata' space, will use ext. RAM
unsigned int i;
```

```
AUXR&=0xFD; //clear AUXR.1 for on-chip XRAM
for (i=0; i<512; i++) G_array1[i]=0x5A; // fill XRAM with 0x5A

AUXR|=0x02; //set AUXR.1 for external RAM
for (i=0; i<512; i++) G_array2[i]=0xA5; // fill ext. RAM with 0xA5
```

Note that there will be a linking warning listed below. However, it doesn't matter because we intentionally declare G_array1 and G_array2 in the same address space. In fact, we access to the different physical memory controlled by bit-1 of AUXR.

```
linking...
*** WARNING L6: XDATA SPACE MEMORY OVERLAP
FROM:      0000H
TO:        01FFH
```

7.3 Code Optimization and Source-Level Debugging

As shown in the following source code, the C51 compiler won't generate any machine code for “*L_var1=0x38;*” because this statement becomes meaningless due to its following statement “*L_var1=0xC7;*”. For code optimization, “*L_var1=0x38;*” will be optimized out unless the code optimization is disabled as described in [Section 4.4](#).

```
unsigned char L_var1;

L_var1=0x38; // ! Note: this statement may be optimized out by the C51 compiler
L_var1=0xC7;
```

So, during source-level debugging, *L_var1* will never show *0x38* but may show a random number when this statement is just executed. In fact, there is no machine code for this statement. The user should pay attention to it!

Sometimes, for debugging purpose, the user may disable the compiler's code optimization. Note that once the compiler's code optimization is disabled, there may be some linking errors which won't occur when the code optimization is enabled. For example, refer to the following linking error message, it means the variables you use exceed the RAM an MCU has. To make this error disappear, the only way is to enable the compiler's code optimization to let the compiler make more efficient use of the RAM.

```
linking...
*** ERROR L107: ADDRESS SPACE OVERFLOW
SPACE:      DATA
SEGMENT: ?DT?_VP_DISPLAYMODE?VP
LENGTH:     0001H
```

7.4 “for-Loop” and Source-Level Debugging

The following two statements are fully the same for the 8051 CPU to execute them. During source-level debugging, there is no problem to apply *Step* action on Statement 1. However, it will take so much time if the user apply *Step* action on Statement 2. We think it is caused by unknown processing in the Keil debugger function. Before we getting the reply from Keil, we suggest using Statement 1 instead of Statement 2 in the source code if you want to do step-debugging in such statement. Another solution for Statement 2 is: move cursor to Line2 and click left key, then click *Run-to-Cursor* button to fly over Line 1.

Statement 1:

```
Line1: for (i=0; i<16; i++) {  
Line2:     G_array1[i]=i+0x60;  
Line3: }
```

Statement 2:

```
Line1: for (i=0; i<16; i++) G_array1[i]=i+0x60;  
Line2: ...  
Line3: ...
```

7.5 Hardware Option Requirements During Debugging

There are two requirements regarding the hardware option in the *dScope-Debugger* mode:

Requirement 1: The debugged chip must be in un-locked state

It is because if the debugged chip is locked, the downloading of the user's application code in the *dScope-Debugger* mode will cause the chip to be whole-chip erased, and therefore all the chip's hardware options will be disabled. Thus the debugged chip may not work well owing to losing its original hardware options. For example, for a locked chip with IAP-memory configured, after downloading the user's application code when entering the *dScope-Debugger* mode, its IAP-memory will disappear (i.e., disabled). So, the chip cannot work well.

Requirement 2: The ISP function of the debugged chip must be disabled

It is because if the ISP function is enabled, the debugged chip will always boot from the ISP-memory and run the ISP-code when the chip receives the *Reset* command in the *dScope-Debugger* mode. It will cause a problem. That is, the code the MCU runs (i.e., the ISP-code) is different from the code of the opened Keil project (i.e., the user's application code). So, during debugging, the user needs to disable the ISP function by having the hardware option *HWBS* disabled temporarily.

Note:


After the application code is debugged completely, the user may use the “Megawin 8051 ICP Programmer” to restore the original hardware option.

7.6 Error Message

There will be an error message “**Error: Target DLL has been cancelled. Debugger aborted !**” shown in following figure if:

- (1) ICE adapter hardware fails, or
- (2) Target MCU doesn't work (for example, not powered on), or
- (3) Cable error or improper connection between ICE adapter and the Target MCU.

Once the error message pops out, click “**OK**”. Then, check the above possible causes to solve the problem.



7.7 Properly Connect the ICE Adapter to a Host

The data transfer rate of the ICE adapter will be slowed down severely if it is connected to a host via a USB2.0 hub. So, to speed up the downloading when clicking *dScope* button to enter the debugger mode, the user had better directly plug the ICE adapter into the host's USB port, as shown in Figure 6.7.1. Don't plug into a hub and then to the host, as shown in Figure 6.7.2.

Figure 6.7.1 Directly plug into the host's USB port





Figure 6.7.2 Don't plug into a hub and then to the host's USB port



Revision History

Revision	Description	Date
v1.00	The first release for beta-site test.	2007/08/15
v1.01	Add notes when installation fails. (Section 3.2)	2007/08/24
v1.02	Change to manually specify the installation path of the Keil software. (Section 3.2)	2007/08/27
v2.00	Add the notification of default installation path of Keil 8051 IDE software. (Section 3.2)	2007/08/29
	Update the Keil IDE Setup. (Section 4.4)	2007/10/08
	Update the Special Notes. (Section 6)	2007/10/08
	The formal released version.	2007/10/08
v2.10	(1) Improve the defect of breakpoint setting. (2) Fix the bug of wrong erasing range when downloading the application code.	2007/12/26
V2.20	(1) Update the data base for all series of MCU in Driver Installer. (2) Removed the function of detecting the ICE adapter when install Driver.	2009/02/27
V2.21	Change the folder name of Driver Install to Database install	2009/04/01
V2.30	(1) Supported MG82FL(E)532 and MG82FL(E)564 (2) Supported ICP function	2010/05/10
V2.31	Update "Database Installer "	2010/05/21
V2.32	Support uVision4	2010/06/02
V2.33	Update "IcpProgrammer.exe" in Database Installer	2010/08/25
V2.40	Supported MG84FG516	2011/05/02
V2.41	Update "IcpProgrammer.exe" in Database Installer	2011/06/01
V2.50	Support Off-Line Mode programming	2011/10/20
V2.51	Support H/W ver.TH065E to prevent to damage the MG84FG516	2012/04/01
V2.52	Fix the bug on ICP function for MG84FG516	2012/05/01
V2.53	Update "IcpProgrammer.exe" in Database Installer	2012/05/15
V2.54	(1) Supported "Maximum Counter" in Off-Line Mode programming (2) Supported " Serial Number " in Off-Line Mode programming (3) Improve the performance on Off-Line Mode programming.	2012/07/12
V2.55	Fix the bug on ICP function	2012/09/28
V2.56	Fix the bug on ICE function	2012/10/08
V2.60	(1) Supported "MPJ" file (2) Database support MG86FL(E)104 and MG86FL(E)508 (3) Supported MG82FG5A64 (4) Update " warning message " when OCD ICE in update processing	2012/12/10
V2.61	(1) Fix a bug for MG84FG516 at access P6M0 in debug mode (2) Update " Megawin.dat "	2013/01/10
V2.62	Update "IcpProgrammer.exe" in Database Installer	2013/01/14
V2.63	Supported MG82FG5A32	2013/06/27
V2.64	Update the Hardware Setup. (Section 2)	2013/09/27
V2.70	(1) Supported MG82FG5B(32/16) (2) Supported MG20FL(E)809	2103/11/15
V2.71	Supported MG82FG5B(24/08)	2104/04/09
V2.72	Update H and INC files in H and INC folder	2014/05/15
V2.90	Supported MG82FG5C(64/32)	2015/04/15

V2.91	Update "IcpProgrammer.exe" in Database Installer	2015/05/21
V2.92	Update "IcpProgrammer.exe" in Database Installer	2015/05/22
V2.93	Update "MegawinOCD.dll" in Database Installer	2015/08/24
V2.94	Update "MegawinOCD.dll" in Database Installer	2015/12/14
V2.95	Support " Auto Reload Code " in IcpProgrammer	2016/09/01
V2.96	Update "IcpProgrammer.exe" in Database Installer	2015/09/26
V3.00	Supported MG82FG5D(08/16)	2017/06/09